








Fig.1 DRIVE UNIT



## Fig. 2 ENGINE GROUP

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
1	5602-12110	Cylinder	1		62	0263-90412	Screw	4	
2	5500-12213	Gasket, base	1		63	5628-83221	Bracket	1	
3	1850-12130	Bolt M5x22	2		64	5500-13131	Gasket, carburetor	1	
4	5500-13163	Insulator	1						
5	5500-13121	Gasket, insulator	1		67	5602-81001	Carburetor ass'y	1	WYL-118
6	5500-13131	Gasket, Carb	1		68	1850-81450	• Body ass'y	1	
7	0263-90520	Screw M5x20	2		69	3306-81380	•• Screen	1	
					70	3356-81310	•• Valve	1	
9	5601-15110	Muffler	1		71	1850-81270	•• Spring	1	
					72	1850-81220	•• Screw	1	
11	01252-30550	Bolt M5x50	2		73	3310-81250	•• Pin	1	
12	5600-15210	Gasket, muffler	1		74	3310-81230	•• Lever	1	
13	5600-15220	Plate, muffler	1		75	5850-81110	• Screw	2	
14	0263-90416	Screw M4x16	1		76	1751-81130	• Ring	1	
15	5600-21100	Crankcase comp.	1		77	1881-81140	• Swivel	1	
16	5500-21141	Gasket, muffler	1						
17	06030-06001	Bearing	2		79	1751-81240	• O-ring	1	
18	2169-21210	Oil seal	1		80	5628-81250	• Jet	1	
19	1850-21220	Oil seal	1		81	3310-81260	• Diaphragm	1	
20	04065-02812	Snap ring	1		82	1065-81410	• Gasket, pump	1	
21	01252-30530	Bolt M5x30	4		83	1065-81420	• Diaphragm, pump	1	
22	5500-22110	Guard	1		84	1850-81470	• Gasket, diaphragm	1	
23	0263-90514	Screw M5x14	1		85	1850-81490	• Body, purge	1	
24	5600-41111	Piston	1		86	1751-81510	• Pump, priming	1	
25	1100-41210	Ring, piston	2		87	1850-81520	• Cover, pump	1	
26	1101-41310	Pin, piston	1		88	1850-81530	• Screw	4	
27	1260-41320	Snap ring	2		89	5500-85510	Screw	3	
28	5500-41410	Bearing	1		90	848-E7N-90C0	Label, recoil	1	
29	1101-41340	Washer	2		91	1601-81810	Cap	1	
30	5600-42001	Crankshaft comp.	1		92	0263-90560	Screw M5x60	2	
31	1650-43230	Nut	1		93	1950-86120	Clip	1	
32	1000-43240	Key	1		94	T1600-82100	Body assy	1	
33	1140-51111	Shoe	2		95	1970-82190	• Sleeve	2	
34	1140-51250	Screw	2		96	T1600-82130	• Plate, choke	1	
35	1600-51223	Spring	1		97	T1600-82140	• Lever, choke	1	
36	1140-51230	Washer	2		98	2630-33610	• Screw	1	
37	1970-51241	Washer	2		99	5500-82171	Element	1	
38	5600-52110	Case, clutch	1		100	5600-82203	Cover assy	1	
39	0263-90516	Screw M5x16	4		101	5500-82221	• Knob	1	
40	5600-52150	Plate, clutch	1		102	5600-31110	Cover, fan	1	
41	1650-43230	Nut	1		103	0263-90520	Screw M5x20	4	
42	5601-71110	Rotor	1		104	5600-32101	Cover, engine	1	
43	5600-71200	Coil ass'y	1		105	1850-32160	Screw M5x12	1	
44	5600-71220	• Cord	1		106	1900-31410	Screw	1	
45	2616-71320	• Cap	1		107	5933-73110	Spark plug	1	BPMR7A
46	5500-72110	Cap, spark plug	1		108	1852-72121	Grommet	1	
47	1900-72120	Spring	1		109	848-8M0-0200	Cord comp	1	
48	5500-72130	Grommet	1		110	5607-85002	Tank ass'y	1	
49	1260-71261	Spacer	2		111	5607-85201	• Cap ass'y	1	
50	3310-72150	Bolt M4x25	2		112	5601-85300	•• Holder ass'y	1	
51	5990-75102	Recoil ass'y	1		113	5601-85260	•• Filter	1	
52	5990-75110	• Case, recoil	1		114	5500-85220	•• Packing	1	
53	5990-75120	• Spring, spiral	1		115	4820-85260	•• Stopper	1	
54	5990-75131	• Reel	1		116	5500-85300	• Pipe comp.	1	
55	5990-75141	• Ratchet	1		117	5500-85400	• Filter ass'y	1	
56	5990-75151	• Spring	1		118	1260-85460	• Clip	1	
57	5990-75270	• Screw	1		119	T2990-21080	Label 108DB	1	
58	5990-75160	• Retainer	1		120	2750-72230	Clamp	1	
59	5990-75170	• Washer	1						
60	1861-75180	• Rope	1						
61	1490-75181	• Knob	1						

**Fig. 2 ENGINE GROUP**





**Fig. 1 DRIVE UNIT**

Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE	Key#	PART NUMBER	DESCRIPTION	Q'TY /UNIT	NOTE
1	848D4F6500	BLADE ASS'Y	1		40	2630-32610	SCREW	2	
2	848D4F66AC	• PLATE, upper	1		41	T4506-32110	HANDLE FRONT	1	
3	848D4F66B0	• PLATE, lower	1						
4	848D4F65A0	• BLADE	2						
5	848D3L66C0	• SPACER	5						
6	848D3L66K0	• SPACER	3						
7	848D3L66H0	• SCREW	5						
8	01252-30520	• BOLT	1						
9	01252-30525	• BOLT	2						
10	848D3L66J0	• NUT	6						
11	848D3L66D0	• PLATE	1						
12	848D3L66E0	• BRACKET	1						
13	848D4F68A0	• COVER	1						
14	848D306112	BOLT	1						
15	06004-06001	• BEARING	2						
16	04065-02812	• GEAR CASE(BoTOOR)	1						
17	848D3061B0	• PLATE	1						
18	T4543-42320	• FELT	2						
19	848D306121	BOLT	1						
20	848D3061B0	• ROD ASS'Y	1						
21	T4543-42320	• GEAR DRIVEN	2						
22	T4543-21220	ROD ASS'Y	1						
23	848D305111	GEAR DRIVE	1						
24	848D3062A0	BOLT	1						
25	T4543-42210	RING	1						
26	T4543-42100	BEARING	2						
27	3199-13350	FITTING	1						
28	T4543-42410	FELT	1						
29	3310-31720	BOLT	4						
30	T4506-31210	• LEVER, throttle	1						
31	T4506-31310	• ARM	1						
32	T4506-31412	• LEVER, lock	1						
33	T4506-31420	• KNOB	1						
34	T4506-31430	• SPRING	1						
35	T4506-51110	• CABLE COMP.	1						
36	T4506-52110	• SWITCH	1						
37	T4506-52120	• CODE COMP.	1						
38	3356-33321	• SPRING, throttle	1						
39	2630-31950	• SCREW	5						